
Telescopic Sliding Frameless Glass 2 Door System Installation Instructions


Installation Instructions:

Notice:


- 1. This system can not be installed in all hidden slot, must have enough space to install.
- 2. The rail must be installed on steel girders or reinforced concrete in enough strong.
- 3. Please clean the inside of rail without any foreign matter , then put roller hardware inside.
- 4. We suggest customer ask serviceman to inspect the sliding door if it is used frequently.

Installation Tools:







Accessories list




1 Left Linkage door




2 Right Linkage door




3 Left Linkage door diagram



4 Right Linkage door diagram



5 Calculation formula of door's width The calculation of Left side example 1 and Right side 1 is the same.




$$B = (L/2) + 50$$


$$A = (L/2) + 50$$


$$F = (L/2) + 60$$


 $P = L + F$

Door height H= Door hole -103mm










6 Calculation formula of door's width The calculation of Left side example 2 and Right side 2 is the same.



$$Z = L - S$$


$$B = (Z/2) + 50$$


$$A = (Z/2) + 50$$


 $F = (Z/2) + 60$


$$P = L + F$$


Door height H= Door hole -103mm



































 $13\,$ Adjust C door 's trigger ,A door and B door 's stopper.

Adjust the K stopper and trigger L according the installation situation.

